



ASSEMBLE WITH BRASS WOOD SCREWS/CORNER HARDWARE AND GLUE
(DO NOT USE DRYWALL SCREWS)

STAIN VERY DARK BROWN TO CONTRAST WITH FLOORING FOR SAFETY